


Scan this barcode to disable the remote display.

Remote Display Disable



Scan this barcode to enable the remote display.

Remote Display Enable

