

Magellan 93/9400i Cell Phone Programming

Scan Enter/Exit and then scan one of the barcodes below. After scanning one of the barcodes below the scanner will exit programming mode automatically and reboot.

Enter/Exit Programming



Enable Cell Phone (10% Frames)



Aggressive on paper barcodes, responsive on cell phone barcodes (recommended for front end lanes)

Enable Cell Phone (20% Frames)



Less aggressive on paper barcodes, more aggressive on cell phone barcodes

Enable Cell Phone (50% Frames)



Responsive to paper barcodes, most aggressive on cell phone barcodes

Disable Cell Phone

